

CONTENT


1. Introduction

Overview	3
Main Features	4

2. Installation

Check List	8
Installation Steps	8
Set Jumpers	9
1. Clear CMOS RAM	10
2. Clear CMOS	10
Install the System Memory	12
1. Adding Memory	12
2. Memory Configuration	12
3. Install and Remove DIMMs	13
Install the CPU	13
1. Install the CPU	13
Connect Cables	15
1. CPU Fan connector	15
2. Primary/Secondary IDE Connectors	15
3. FDD connector	15
4. IR Connectors	15
5. Wake On Lan Connector	15
6. Front Panel Switch connector	16
7. Power Switch Connector	17
External Connectors	18
1. PS/2 Keyboard & Mouse Connector	18
2. Serial Port COM1 and COM2	18
3. Parallel Port Printer Connector	18
4. VGA PORT	19





5. Universal Serial Bus Connector	19
6. Audio Jacks	19
 Driver Installation.....	19
1. Installing the inf files from Driver CD	20
2. Installing the inf update utility.....	20
3. Installing the VGA driver from CD-ROM	21
4. AC97 Audio WDM driver installation.....	23
 3. Setup	
1. MAIN Setup Menu	26
2. Advanced Setup Menu	29
3. Security Setup Menu	31
4. Power Setup Menu	34
5. Boot Setup Menu.....	36
6. Exit Setup Menu	38

